


SOLARA 5000



SPINNING REEL



PARTS LIST SOLARA 5000

NO.	PARTS NO.	PARTS NAME	NO.	PARTS NO.	PARTS NAME	NO.	PARTS NO.	PARTS NAME
1	0232202	DRAG KNOB ASSY.	23	0041559	COVER A	45	0009340	PINION GEAR
2	00420:9	STOPPER SPRING	24	0020401	SCREW	46	0049063	CONTROL PLATE
3	026:576	CLICK PLATE ASSY.	25	0020657	SCREW	47	006:56:	OUTER RING
4	0026454	DRAG WASHER	26	0067139	DEAD POINT SPRING	4:	0203371	MAIN BODY ASSY.
5	0026455	DRAG WASHER	27	0205266	ROTOR	49	02073:6	HANDLE ASSY.
6	0026456	DRAG WASHER	2:	0041560	COVER B	50	0030170	PRESSURE PLATE
7	0206615	SPOOL ASSY. (5000)	29	0020401	SCREW	52	0014369	ANTI-REVERSE CAM
:	0033337	CLICK CLAW	30	0229367	BAIL ARM ASSY.	54	006:590	SPACER
9	0067144	CLICK CLAW SPRING	31	0027705	WASHER	55	0041571	PROTECTOR
10	0021157	CLICK CLAW SCREW	32	0252003	ROLLER	56	002006:A	SCREW
11	0219502	HANDLE CAP ASSY.	33	003:157	BALL BEARING	57	0015710	ANTI-REVERSE LEVER
12	0067143	ONE WAY CLUTCH SPRING	34	0017455A	COLLAR	5:	0010501	BULL GEAR
13	0027724	CLICK WASHER	35	0015705	BAIL ARM LEVER	59	0011163	OSCILLATOR
14	0013123	CLICK	36	0020656	SCREW	60	0020654	SCREW
15	0027725	SPOOL WASHER	37	0015706	SCREW	61	003:227	BALL BEARING
16	0034065	SHAFT	3:	0020401	SCREW	62	000:2:9	MAIN GEAR
17	0020607	SCREW	39	0030169	BEARING SUPPORT	63	0027176	WASHER
1:	001:05:	HEXAGON NUT	40	003:226	BALL BEARING	64	0004520	SIDE PLATE
19	0020561	SCREW	41	0017499	BALL BEARING COLLAR	65	002043:	SCREW
20	006:569	SLIDER	42	006:570	HOLDER	66	0021106	HANDLE SCREW
21	006:572	LINK	43	0025097	ROLLER			
22	0015707	KICK LEVER	44	001744:	INNER RING			